

UKKO S


Installation Manual



1

Disassemble the outer packaging carton of the vehicle.

2



Remove the tightening belt of the vehicle, take out the accessory carton, the front fender carton, and the front tire assembly.

3



Remove the M6×12 hexagon flange bolts used for fixing at the lower part of the packaging frame to remove the upper part of the packaging frame.

4



Adjust the angle of the handlebar, and then tighten the bottom four M8×25 hexagon socket head cap screws with a torque of 15~22 N·m.

5



Take out the $\Phi 12 \times 193$ front wheel axle, and remove the lower part of the packing frame.

6



Install the front panel, and tighten a total of six M6×12 hexagon socket screws at both the left and right side of the vehicle, the torque is 6~9 N·m.

7



Install the front tires and the shaft sleeves of the front tires at both right and left side (the length of the left shaft sleeve is 21.5mm, the length of the right shaft sleeve is 38mm), lock the front axle of $\Phi 12 \times 193$, the torque is 50~60 N·m.

8



Use a wrench with an opening of 14 to install and lock the rearview mirrors.